



1.9 Difuser polishing process

Our 1.9" Difuser beadlock wheels look best when polished. To polish the centers before mounting the tires and rings follow this quick how to.

1. Chuck up the wheel in a cordless drill and hit them with a 320 wetsand. This will leave radial marks in them which look like the vintage wheels did.

(You can use a drill press as well but it's just as easy with common household tools.)

2. Go to round 2 with a 600 wet sand. If you like the radial look, you can stop here. If you want extra bling, keep going to step 3.

3. To bling finish the wheels you can use Mothers alum polish. Apply the polish by finger with the wheel still on the drill and finish with a paper towel.

Then a quick rinse in the sink to get the polish out of the bolt hole and you are ready to mount them up.

