


Warn Winch Instruction manual Wireless


1. Connect the winch plug into the winch/control box plug.




2. Plug winch/control box plug into control box marked W+/W-.
(Check Direction of your wires and plug, Red +, Black -)



3. Plug the battery into the power connection wire.



4. Push and hold the bind button on the wireless control box while plugging in the battery connection.




Warn Winch Instruction manual Wireless

5. Remove the battery tag to allow power to the TX.



6. Push and hold both buttons on the TX to allow binding to take place.



7. Plug in winch plug wire into control box and check operation of the winch.

